



RIDGI Fence Bracket Installation Guide

You will need: RIDGI 3mm fence brackets, 10mm nyloc bolt, cordless drill, 8mm allen key and socket to suit, marking pen

- Line up fence bracket on post, mark on the post where you require holes.
- Drill 2, 3mm holes through the posts then over that drill a 10mm hole. This allows easier drilling.
- Line up fence bracket on holes, insert bolts and tighten the nuts to secure to the post.
- Insert the top 2 rows of the concrete sleepers.

Helpful tip: When installing the steel posts ensure you allow an extra 15-30mm spacing to have enough clearance for the bolts.

Engineer note: Depending on your soil conditions you may need to allow extra pier depth when putting a fence on top. As a guide, we recommend having an extra 400mm deeper pier when putting a standard 1.8m fence on top. If you are unsure consult an engineer or call us on 07 3348 1200.